

# Omnia-3 Software Update Instructions

\*\*\* Important Notes! Please Read! \*\*\*

- ?? If upgrading from an older NON-TURBO version of Omnia-3 FM: Once you have completed the upgrade please **do not attempt to load a previously saved system file, user preset or trigger script** using the remote control software. Older files, scripts and processing presets that were saved using previous versions of the Omnia-3 FM (non- Turbo) are not compatible with the Fm Turbo release and loading one may cause level discrepancies or other unpredictable results.
- ?? Omnia-3 Remote Control Version 3.5.1 or higher must be used with the software enclosed in this update kit. Previous versions are now incompatible and will not operate properly. The latest version may always be freely downloaded from:

<http://www.omniaaudio.com/support/updates.htm>

If you have questions or find that you require assistance with this upgrade, you may call Customer Support at 1.216.241.7225. Please have the serial number of your unit handy if you need to call us. The serial number can be found on a small barcode sticker on the rear panel that looks like this: 430xyyyy.

## Software Update Procedure

- 1) Remove the Omnia-3 from service and disconnect power from the unit.
- 2) Remove the old PCMCIA software card that from the **top** PCMCIA slot on the rear panel by pressing the black release button to the right of the card to release the card and then remove it from the slot and set it aside.
- 3) Carefully insert the new memory card into the **top** slot of the Omnia-3's rear panel with the large Omnia logo facing up and the version number sticker facing down. Make certain that the card is properly aligned with the socket. Note that inserting the memory card upside down or into the bottom slot (which is for the optional modem only) can irreparably damage the card and/or the socket.
- 4) Press the card gently but firmly into the top slot until it is fully seated. Do NOT apply excessive force! The card should seat easily into the socket with only slight resistance. When fully seated, the black release button should pop out about 1/2" [12.70 mm].
- 5) Connect the AC power cord, and turn on the power switch. An error message may appear that says "Cannot Load System. Older Version." This is normal. Simply click the jog wheel once to clear it and the Main Menu should appear.

The update procedure is completed. You may now re-install the unit to service.

**You will now need to return the old card you just removed to Telos / Omnia. Once we have received the card, a full credit will be issued.**

## STAY IN TOUCH

Please log on to <http://www.omniaaudio.com/> to register for our email newsletter and to take advantage of upgrades and other important information designed to keep your Omnia at optimum performance.